

Hard tube

1.
Soak the hard tubes in hand-hot water for approx. 30 minutes, as usual.
2.
Remove the hard tube from the water and push the tube on to the filling pipe.
3.
You can now pull out the tube with one hand, while keeping hold of the casing on the filling pipe in front of the separator with the other.
4.
Now remove the frontmost separator and you can start filling.



DARME
SCHÖNHOFER GMBH

